



**RNAV STANDARD DEPARTURE CHART - INSTRUMENT
(SID) - ICAO**

**PRAHA/RUZYŇĚ
RNAV SID RWY 06**



RNAV-1 required
After departure contact Praha Radar ...120,530
Description of all TRA GA areas see ENR 5.5

PRAHA APPROACH / RADAR	120.530
RUZYŇĚ APPROACH / RADAR	119.010
RUZYŇĚ RADAR / INFORMATION	118.310
SUPPLEMENTARY FREQ APP	136.080
RUZYŇĚ DELIVERY	120.060
RUZYŇĚ TOWER	134.560
SUPPLEMENTARY FREQ TWR	118.110
RUZYŇĚ GROUND	121.910
RUZYŇĚ ATIS	122.160
EMERGENCY FREQ	121.500



TRANSITION ALTITUDE
5000

DEPARTURE SPEED LIMIT BELOW FL 100	
JETS	MAX IAS 250 KT
PROPS	MAX IAS 180 KT

BEARINGS, TRACKS AND
RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS
ARE IN FEET
DISTANCES ARE IN NM

see AIP AD 2-LKPR-33, 2.22.4.3.5