


RNAV STANDARD DEPARTURE CHART INSTRUMENT

OSTRAVA/MOŠNOV

(SID) - ICAO

RNAV SID RWY 04




SID segments outside TMA Ostrava cross through airspace "Class E" below FL 95

Pilots who require provision of ATC service in Poland shall climb so to pass BAVOK / REGLI / NETIR at FL100 or above due to airspace "Class G" up to FL 95. If unable, advise ATC and expect vectors.

RNAV 1 REQUIRED

PRAHA RADAR	119.375
MOŠNOV DELIVERY	128.525
MOŠNOV TOWER	120.805
MOŠNOV ATIS	118.055
EMERGENCY FREQ	121.500

MSA  
VOR/DME OTA



BEARINGS, TRACKS AND RADIALS ARE MAGNETIC  
ALTITUDES AND ELEVATIONS ARE IN FEET  
DISTANCES ARE IN NM

TRANSITION ALTITUDE  
5000

change: FREQ PRAHA RADAR 128.525 withdrawn; MAG VAR: FREQ MOŠNOV DELIVERY from 118.700 to 128.525