


**RNAV STANDARD DEPARTURE CHART - INSTRUMENT
(SID) - ICAO**

**KARLOVY VARY
RNAV SID RWY 11**



SID segments outside TMA Karlovy Vary cross through airspace "Class E" below FL 95

TMA
TMA III KARLOVY VARY
FL 95
4000 AMSL

CTR
CTR KARLOVY VARY
3500 AMSL
GND

CHEB
VOR/DME 115.700
OKG
500354.53N
0122420.66E
1600 ft


TMA
TMA II KARLOVY VARY
FL 95
FL 75

TMA
TMA I KARLOVY VARY
FL 95
3500 AMSL

TMA
TMA IX PRAHA
FL 165
FL 95

TMA
TMA VI PRAHA
FL 95
FL 75

| | |
|-------------------------------|---------|
| KARLOVY VARY APPROACH / RADAR | 118.650 |
| KARLOVY VARY TOWER | 119.955 |
| KARLOVY VARY ATIS | 121.230 |
| EMERGENCY FREQ | 118.955 |
| | 121.500 |



TRANSITION ALTITUDE
5000

BEARINGS, TRACKS AND RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS ARE IN FEET
DISTANCES ARE IN NM

