



**RNAV STANDARD ARRIVAL
CHART INSTRUMENT
(STAR) - ICAO**

PRAHA RADAR	118.650
VARY TOWER	121.230
KARLOVY VARY ATIS	118.955
EMERGENCY FREQ	121.500




**KARLOVY VARY
RWY 11**



BEARINGS, TRACKS AND RADIALS ARE
MAGNETIC
ALTITUDES AND ELEVATIONS ARE IN FEET
DISTANCES ARE IN NM

STAR segments outside TMA Karlovy
Vary cross through airspace "Class E"
below FL 95



Change: FREQ CallSign KARLOVY VARY RADAR to PRAHA RADAR
KARLOVY VARY TOWER to VARY TOWER