


RNAV STANDARD DEPARTURE CHART INSTRUMENT

OSTRAVA/MOŠNOV

(SID) - ICAO

RNAV SID RWY 04



SID segments outside TMA Ostrava cross through airspace "Class E" below FL 95


Pilots who require provision of ATC service in Poland shall climb so to pass BAVOK / REGLI / NETIR at FL100 or above due to airspace "Class G" up to FL 95. If unable, advise ATC and expect vectors.

RNAV 1 REQUIRED

VAIF 5°E 2020

PRAHA RADAR	119.375
MOŠNOV DELIVERY	128.525
MOŠNOV TOWER	120.805
MOŠNOV ATIS	118.055
EMERGENCY FREQ	121.500

MSA
VOR/DME OTA



BEARINGS, TRACKS AND RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS ARE IN FEET
DISTANCES ARE IN NM

TRANSITION ALTITUDE
5000