



**RNAV STANDARD ARRIVAL CHART - INSTRUMENT
(STAR) - ICAO**

**PRAHA/RUZYŇĚ
RNAV STAR RWY 06**



| | |
|----------------------------|---------|
| PRAHA APPROACH / RADAR | 120.530 |
| RUZYŇĚ APPROACH / RADAR | 127.580 |
| RUZYŇĚ RADAR / INFORMATION | 119.010 |
| SUPPLEMENTARY FREQ APP | 118.310 |
| RUZYŇĚ DELIVERY | 136.080 |
| RUZYŇĚ TOWER | 120.060 |
| SUPPLEMENTARY FREQ TWR | 134.560 |
| RUZYŇĚ GROUND | 118.110 |
| RUZYŇĚ ATIS | 121.910 |
| EMERGENCY FREQ | 122.160 |
| | 121.500 |



BEARINGS, TRACKS AND RADIALS ARE MAGNETIC ALTITUDES AND ELEVATIONS ARE IN FEET DISTANCES ARE IN NM

Speed restriction see AIP AD 2-LKPR-30, 2.22.4.2.1