


**RNAV STANDARD
DEPARTURE CHART
INSTRUMENT (SID) - ICAO**

PRAHA RADAR 127.350
KUNOVICE TOWER 120.105
EMERGENCY FREQ 121.500

MSA NDB KNE




**KUNOVICE
RWY 02C**

BEARINGS, TRACKS AND
RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS
ARE IN FEET
DISTANCES ARE IN NM

TRANSITION ALTITUDE
5000

Departure routes may cross through airspace class E.
Check lower limits of TMA BRNO

RNAV 1 REQUIRED



change: new TRAGA KYJOV

