

1 LOCAL TRAFFIC REGULATIONS AND RESTRICTIONS

- 1.1 The traffic circuits:
- RWY 09 - right hand traffic circuits,
 - RWY 27 - left hand traffic circuits.
- 1.2 Aircraft model air field in close vicinity of RWY. Movement of unmanned systems above the aerodrome is coordinated during operation at the aerodrome. Be careful.
- 1.3 ATZ is restricted horizontally by CTR Ruzyně and vertically by lower limit of TMA I Praha (2500 ft AMSL on QNH of LKPR).
- 1.4 Aeroplanes arriving to RWY 09 can fly only outside of CTR Ruzyně, or can request clearance for entry to the CTR on FREQ Ruzyně Radar 118,310.
- 1.5 Taxiing along RWY only or according to instructions of the officer of Providing information to known traffic.
- 1.6 Snow clearance is not provided.
- 1.7 RWY is unserviceable after prolonged rains
- 1.8 The aerodrome operator guarantees AD fire category 2. The operator does not guarantee fire category 3 or higher.

2 ADDITIONAL INFORMATION

- 2.1 The application for use of the aerodrome can be obtained by email, phone or before landing on frequency Točná RADIO.
- 2.2 If English is necessary, it is possible to receive approval by email at airport@tocna.cz at least 48 hours in advance.
- 2.3 Use RWY center for taxiing, not the safety strips.
- 2.4 Lipence aircraft model air field with occasional operation of larger models, about 3,5 km from Točná airport in the direction of point Echo. Use extra caution.

3 CHARGES FOR AERODROMES

3.1 Landing charges

Up to 500 kg	200,00
Up to 1000 kg	300,00
Up to 2000 kg	400,00
Over 2000 kg	800,00

3.2 Parking charges

Outside parking over 48 hrs (per day)	500,00
---------------------------------------	--------

3.3 Charges for passenger service

NIL

Chapter end

