1 LOCAL TRAFFIC REGULATIONS AND RESTRICTIONS

- 1.1 The aerodrome is located in MTMA Čáslav, local restriction see LKTRA31, LKTSA20 and LKTSA27 (see AIP CR ENR 5.2).
- 1.2 RWY can be unserviceable after prolonged rains or when is covered by snow. Snow clearance is not provided.
- 1.3 Arrival without two-way radio communication is possible only after previous agreement with the aerodrome operator.
- 1.4 The traffic circuit altitude is 2800 ft / 850 m AMSL.
- 1.5 Noise abatement procedures
- 1.5.1 After take-off from RWY 35 turn left to avoid village Dobkov and cottages near a dam.
- 1.5.2 During flight in traffic circuit do not overfly villages Počátky, Dobkov and cottages near a dam north of the aerodrome.

2 ADDITIONAL INFORMATION

- 2.1 Arrivals to the aerodrome outside operational hours are permitted only after previous agreement with the aerodrome operator (check of serviceability of movement areas).
- 2.2 Providing information to known traffic in english language on request 24H in advance.

3 CHARGES FOR AERODROMES

3.1 Landing charges

Up to two tonnes of MTOW	100,00
Exceeding two tonnes - per each initiated tonne	100,00

3.2 Parking charges

Passenger	NIL
-----------	-----

3.3 Charges for passenger service

NIL

Chapter end -

