STANDARD DEPARTURE CHART - INSTRUMENT (SID) - ICAO

PRAHA/RUZYNĚ RNAV SID RWY 12



VOZ 5Q

Only for propeller driven aircraft between 0500 - 2100 (0400 - 2000) UTC when RWY 24 is in use.

VOZ 1L

Only for propeller driven aircraft between 0500 - 2100 (0400 - 2000) UTC when RWY 06 is in use.

PRAHA RADAR	120.530
	127.580
RUZYNĚ RADAR	119.010
RUZYNĚ RADAR	118.310
SUPPLEMENTARY FREQ APP	136.080
RUZYNĚ DELIVERY	120.060
RUZYNĚ TOWER	134.560
SUPPLEMENTARY FREQ TWR	118.110
RUZYNĚ GROUND	121.910
RUZYNĚ ATIS	122.160
EMERGENCY FREQ	121.500

MSA VOR/DME OKL

180° 25 3600 3200 045° 340° 4000

TRANSITION ALTITUDE 5000

BEARINGS, TRACKS AND RADIALS ARE MAGNETIC ALTITUDES AND ELEVATIONS ARE IN FEET DISTANCES ARE IN NM

DEPARTURE SPEED LIMIT BELOW FL 100	
JETS	MAX IAS 250 KT
PROPS	MAX IAS 180 KT

see AIP AD 2-LKPR-33, 2.22.4.3.5